

LS1 Coil Wiring Diagram

Part Number: H-COIL-LS1
Connector Part Number: H-COIL-LS1C

Drawing Revision 1 - 23/8/2012



www.youtube.com/efihardware



info@efihardware.com



www.facebook.com/efihardware



(03) 9873 5400 +613 9873 5400



(03) 9873 5955 +613 9873 5955



www.efihardware.com

ECU Ignition Output ECU Ground Switched Ignition +12V NOTE: Coil has in-built igniter. Dwell begins when ECU signal goes high (more than 4V) Spark Event occurs when ECU signal goes low (less than 1 V) Recommend Dwell Time: 3.5mS @ 14.4V. **Engine Power** Ground