GT101 Wiring Diagram

Part Number: H-GTSEN

Connector Part Number: N/A

Drawing Revision 1 - 12/9/2013

www.youtube.com/efihardware

www.facebook.com/efihardware

www.efihardware.com

info@efihardware.com

(03) 9873 5400
+613 9873 5400

(03) 9873 5955
+613 9873 5955



NOTE:

The GT101 Sensor pulls the Output Signal wire to ground when a ferrous material is at the sensor face.

The GT101 Sensor releases the Output Sensor wire when there is no ferrous material at the sensor face.