

## EFI Hardware Counter Clockwise - Ford Sequential Distributor Triggering

Installation Instructions
Drawing Revision 1 - 12/11/2013

(idle, full power, cruise, etc).



www.youtube.com/efihardware



info@efihardware.com



www.facebook.com/efihardware


www.efihardware.com



(03) 9873 5400 +613 9873 5400



(03) 9873 5955 +613 9873 5955



The SYNC Pulse tells the ECU when the engine returns back to the first cylinder in the firing order.

EFI Hardware Mobile Apps

www.efihardware.com/apps.php